



RUFF RIDE THERMAL PTZ Quick Pre-Set Guide

Special Control Commands

The camera can be programmed and operated using various quick control commands listed as below.

Preset Number	Function	Default Value
21	Manual switch between color mode and mono mode	Delault value
22	Auto switch between color mode and mono mode	√
23		Off
23	Turn on/off Wide Dynamic Range (WDR)	Off
	Turn on/off Hight Sensitivity	
25	Turn on/off Back Light Compensation (BLC)	Off
26	Turn on/off Image Flip	Off
27	Turn on/off Digital Noise Reduction (DNR, 1-5steps)	Off
28	Turn on/off image freeze	Off
31	1080160	√
32	1080I50	
33	1080P30	
34	1080P25	
35	720P30	
36	720P25	
37	720P60	
38	720P50	
39	Turn on/off digital zoom	Off
40	Turn on/off on screen display	On
42	Set Left Boundary Of Frame Scan	-
43	Set Right Boundary Of Frame Scan	-
44	Turn on Gyroscope Stabilization (Optional)	
45	Turn off Gyroscope Stabilization (Optional)	



RUFF RIDE THERMAL PTZ Quick Pre-Set Guide

SEE BOTH SIDES

48	Turn on random scan	-
49	Turn on frame scan between two set presets	-
50	Turn on cruise 1	-
51	Turn on Auto Scan(360° Scan)	-
52	Clear all Presets	-
53	Restore factory default and reboot the camera	-
54	Set thermal palette	White Hot
55	Reboot PTZ	
56	Turn on/off PTZ Sleep Mode	-
57	Turn On/Off Screen Tips / Page Down Of Screen Tips	
58	Choose a camera module (daylight/thermal) to control	-
59	PTZ Speed - Fast	√
60	PTZ speed - Normal	-
61	PTZ speed - Slow	-
62	Decrease the camera Address By -1	-
63	Increase the camera Address By +1	-
64	Enter Menu	-

